




Operating manual

(Translation of the original instructions)



SILU CS85
SILU CS1050 LITE
SILU CS1050 IC

DE WICHTIG!

Die Betriebsanleitung liegt in Ihrer Landessprache zusammen mit der Montageanleitung (englische und deutsche Ausführung) elektronisch auf der Webseite www.ingersoll.com/ghhrandtransport für den Download bereit. Auf Anfrage senden wir Ihnen auch gerne eine gedruckte Version zu.

EN IMPORTANT!

The operating instructions can be downloaded electronically in your language, together with the mounting instructions (in English and German) from the website www.ingersollrand.com/ghhrandtransport. On request, we will gladly send you a printed version.

CZ DŮLEŽITÉ!

Návod k provozu je k dispozici ke stažení v jazyce Vaší dané země společně s návodem pro montáž (anglická nebo německá verze) elektronicky na webové stránce www.ingersollrand.com/ghhrandtransport. Na vyžádání vám rádi zašleme i tištěnou verzi.

DK VIGTIGT!

Denne driftsvejledning på dit lands sprog ligger elektronisk og klar til download sammen med monteringsvejledningen (engelsk og tysk version) på hjemmesiden www.ingersollrand.com/ghhrandtransport. Efter forespørgsel sender vi dig også gerne en trykt version.

ES ¡IMPORTANTE!

El manual de instrucciones en su idioma junto a las instrucciones de montaje (en inglés y alemán) está disponible para su descarga en formato electrónico en www.ingersollrand.com/ghhrandtransport. Si lo desea, podemos enviarle también un ejemplar en papel.

FR IMPORTANT !

Vous pouvez télécharger la manuel d'utilisation dans la langue de votre pays avec les instructions de montage (en anglais et en allemand) au format électronique sur le site web www.ingersollrand.com/ghhrandtransport. Sur demande, nous vous enverrons volontiers une version imprimée.

IT IMPORTANTE!

Le istruzioni d'esercizio sono disponibili in formato elettronico per il download sul sito www.ingersollrand.com/ghhrandtransport in lingua italiana, insieme alle istruzioni per il montaggio (edizione in inglese e in tedesco). Su richiesta saremo lieti di inviarvene anche una copia in formato cartaceo.

NL BELANGRIJK!

De gebruikshandleiding kan samen met de montagehandleiding (Engelse en Duitse versie) in uw taal elektronisch worden gedownload van de website www.ingersollrand.com/ghhrandtransport. Op aanvraag sturen we u met alle plezier ook een gedrukte versie.

PL WAŻNE!

Instrukcja obsługi dostępna jest w ojczystym języku użytkownika wraz z instrukcją montażu (w języku angielskim i niemieckim) w elektronicznej formie do pobrania na stronie internetowej www.ingersollrand.com/ghhrandtransport. Na życzenie chętnie prześlemy Państwu również wersję drukowaną.

PT IMPORTANTE!

O manual de instruções está pronto para ser descarregado na sua língua-mãe, juntamente com o manual de montagem (versão em inglês e alemão), em formato eletrónico na página web www.ingersollrand.com/ghhrandtransport. A pedido, podemos também fornecer-lhe uma versão impressa.

SE VIKTIGT!

Bruksanvisningen går att hämta elektroniskt på landets språk tillsammans med monteringsanvisningen (på engelska och tyska) på webbsajten www.ingersollrand.com/ghhrandtransport. På begäran skickar vi även gärna ett tryckt exemplar.

FI TÄRKEÄÄ!

Suomenkielisen käyttöohjeen ja (englannin- ja saksankielisen) asennusohjeen voi ladata sähköisessä muodossa osoitteesta www.ingersollrand.com/ghhrandtransport. Pyydettyessä lähetämme myös tulostetun version.

RO IMPORTANT!

Instrucțiunile de exploatare în limba țării dvs., împreună cu instrucțiunile de montaj (versiunea în limba engleză și germană) sunt disponibile pentru descărcare în format electronic pe site-ul web www.ingersollrand.com/ghhrandtransport. De asemenea, la cerere vă putem trimite o versiune tipărită.

HU FONTOS!

Az üzemeltetési útmutató az Ön nyelvén a szerelési útmutatóval (angol és német nyelvű változat) együtt elektronikusan letölthető a www.ingersollrand.com/ghhrandtransport webhelyről. Kérésére szívesen küldünk egy kinyomtatott változatot is.

BY ВАЖНА!

Электронную версію кіраўніцтва па эксплуатацыі на нацыянальнай мове разам з інструкцыяй па мантажы (на англійскай і нямецкай мовах) можна спампаваць на сайце www.ingersollrand.com/ghhrandtransport. Па асобным запыце мы з задавальненнем дашлем вам друкаваную версію.

LT SVARBU!

Elektroninę eksploataavimo instrukcijos Jūsų šalies kalba versiją kartu su montavimo instrukcija (anglų ir vokiečių kalbomis) galite atsisiųsti iš interneto svetainės www.ingersollrand.com/ghhrandtransport. Jei pateiksite užklausą, mielai atsiųsime ir išspausdintą versiją.

Introduction

Before installing and commissioning the SILU CS85 screw compressor or the SILU CS1050 LITE, SILU CS1050 IC compressor units, please read through these operating instructions carefully (the additional designation SILU is not used in the rest of these operating instructions).

The operating manual contains important instructions which must be strictly followed if trouble-free operation and a long service life are to be ensured.

Scope of application of the operating manual

These operating instructions only contain instructions for the above-mentioned screw compressor and the above-mentioned screw compressor units. These operating instructions are not valid for operation of a compressor unit completed by an external installer.

Target group

The operating manual is intended for use by qualified specialist staff only.

Notes and safety instructions

The following instructions and safety instructions are used in the operating manual to warn of dangers which could lead to operating errors, injuries and tangible damage:

DANGER

DANGER warns of an imminent danger and indicates an imminent danger. This safety note warns of possible irreversible to fatal injuries.

WARNING

WARNING indicates a possible imminent danger. This safety note warns of serious or perilous injuries.

CAUTION

CAUTION indicates a possible imminent danger. This safety note warns of light injuries.

NOTICE

ATTENTION warns of possible tangible damage or malfunctions.

NOTE

NOTES contain instructions to prevent operating errors and other specific useful or important information.

Contents

1	GENERAL	7
1.1	Application	7
1.2	Manufacturer's address	7
1.3	Identification.....	7
1.4	Information for enquiries and orders	7
1.5	Service & Support	7
1.6	Technical data CS85 screw compressor.....	8
1.7	Technical data CS1050 compressor units.....	9
1.8	Operating the compressor at high altitudes.....	10
1.9	Lubricant	10
1.10	Screw compressor type plate.....	11
1.11	Compressor unit type plate.....	11
2	SAFETY	12
2.1	General.....	12
2.2	Authorised personnel, training and qualification.....	12
2.3	Safety-conscious work.....	12
2.4	Safety instructions for the owner/operator	12
2.5	Unauthorised conversions and spare parts.....	13
2.6	Incorrect operating methods.....	13
2.7	Disposal.....	13
3	OPERATION	14
3.1	Safety during operation	14
3.2	Initial commissioning	14
3.3	Installation	15
3.4	Switching on	15
3.5	Monitoring operation.....	16
3.5.1	CS85/external installation	16
3.5.2	CS1050 LITE.....	16
3.5.3	CS1050 IC	18
3.6	External oil cooler for compressor (optional)	19
3.6.1	Function control of external oil cooler fan	19
3.7	Switching off	20
3.8	Preservation	20
4	MAINTENANCE/REPAIR	21
4.1	Safety.....	21
4.2	Observe the tightening torques	21
4.3	Maintenance Intervals.....	22
4.4	Maintenance work.....	23
4.4.1	Readjusting the tension of the V-belts and quick-release bushings of the V-belt pulleys	23
4.4.2	Retightening the fastening screws on the discharge silencer	25
4.4.3	Checking the oil level.....	26
4.4.4	Cleaning and replacing the intake filter element	27
4.4.5	Check the safety valve	28
4.4.6	Check the non-return flap	29
4.4.7	Testing and cleaning the air cooler	29
4.4.8	Oil change and cleaning the oil intake strainer	30

5 FAULTS, CAUSE AND INSTRUCTIONS FOR TROUBLESHOOTING 31

1 General

1.1 Application

GHH RAND builds and supplies the CS85 screw compressor and the CS1050 screw compressor unit.

Because of their oil-free compression of atmospheric air and their power-to-weight ratio for installation on silo vehicles, the compressor unit is used to pneumatically convey bulk goods, such as flour, sugar, salt, animal feed, powdered chemicals, dry granulate, soda, cement, sand, lime, plaster, etc.

The products built and supplied by GHH RAND are only designed for the operation at and on utility vehicles that exclusively drive on paved roads.

A different use requires consultation with the manufacturer.

1.2 Manufacturer's address

GHH RAND
Schraubenkompressoren GmbH
Max-Planck-Ring 27
46049 Oberhausen

1.3 Identification

For the machine data, refer to the accompanying documents and the rating plate.

In order to always have the data on hand, we recommend that you enter it into the following blank space.

Compressor serial no.:

Unit serial no.:

1.4 Information for enquiries and orders

If you have enquiries or orders for spare parts and accessories, please provide details of the exact type designation and the serial number of the screw compressor or the compressor unit, for which the spare part or accessory is intended.

CAUTION

USE OF UNAUTHORISED SPARE PARTS AND ACCESSORIES!

Original replacement parts and accessories that are authorised by the manufacturer represent safety factors. The use of non-original or non-authorized replacement parts and accessories may void the liability for the resulting consequences.

- ▶ Only use original spare parts and accessories authorised and approved by the manufacturer.

1.5 Service & Support

www.ingersollrand.com/ghhrandtransport

1.6 Technical data CS85 screw compressor

Dimensions & weight			Rotational speed range	
Length (approx.)	mm	615	min. rpm	1000
Width (approx.)	mm	290	max. rpm	2000
Height (approx.)	mm	396		
Weight (approx.)	kg	149		
Maximum operating pressure			Oil filling quantity	
max. 2.5 bar			approx. 8.5 litres	
Maximum intake negative pressure			Minimum oil pressure	
max. 65 mbar			min. 0.3 bar	

Performance data	Unit	CS85		
Rotary valve compressor	rpm	1000	1500	2000
Operating overpressure	bar	1.5		
Intake volume	m ³ /h	435	724	989
Coupling output	kW	20.5	33.1	47.7
Final temperature	°C	147	143	150
Intake temperature max.	°C	50	50	50
Intake temperature min.	°C	-20	-20	-20
Operating overpressure	bar	2.0		
Intake volume	m ³ /h	420	710	975
Coupling output	kW	25.0	39.2	55.4
Final temperature	°C	183	171	175
Intake temperature max.	°C	50	50	50
Intake temperature min.	°C	-20	-20	-20
Operating overpressure	bar	2.5		
Intake volume	m ³ /h	404	695	962
Coupling output	kW	29.6	45.6	63.4
Final temperature	°C	223	201	202
Intake temperature max.	°C	36	46	45
Intake temperature min.	°C	-20	-20	-20

All information for:

Feed medium:	atmospheric air
Intake pressure:	1 bar (abs.)
Intake temperature:	20 °C

Technical data without intake or pressure losses

1.7 Technical data CS1050 compressor units

Dimensions & weight		CS1050 LITE R-PTO L	CS1050 LITE L-PTO R	CS1050 IC R-PTO L	CS1050 IC L-PTO R
Width (approx.)	mm	834	845	905	926
Depth (approx.)	mm	723	723	775	776
Height (approx.)	mm	713	717	716	739
Weight (approx.)	kg	296	297	399	399

Speed range at standard ratio*	Unit	CS1050 units		
Compressor unit drive speed	rpm	800	1200	1600
V-belt drive transmission ratio (standard)		1.25		
CS85 compressor rotational speed	rpm	1000	1500	2000

* Transmission ratio may vary. Several V-belt drives are available from the factory for the transmission ratio (adjustable to the auxiliary drive installed in the vehicle).

NOTICE

DAMAGE TO THE COMPRESSOR!

Exceeding the permitted speed range leads to material damage.

- ▶ Do not operate the compressor outside of its permitted speed range.

Maximum operating pressure

max. 2.5 bar

Oil filling quantity

approx. 8.5 litres

Maximum intake negative pressure

max. 65 mbar

Minimum oil pressure

min. 0.3 bar

NOTE

The performance data of the CS1050 compressor unit correspond to screw compressor CS85 (*Chapter 1.6 on page 8*).

1.8 Operating the compressor at high altitudes

If operating the compressor at high altitudes, make sure that, depending on the existing ambient pressure, the operating overpressure must be reduced in order to prevent temperature damage to the compressor.

This should be carried out in accordance with the following table:

Installation height h [m]	0	1000	1500	2000	2500	3000	3500	4000	4500
Permitted operating overpressure $p_{permitted}$ [bar]	2.53	2.25	2.11	1.99	1.87	1.75	1.64	1.54	1.44

NOTICE

TEMPERATURE DAMAGE!

An ambient temperature outside the permitted range can result in damage to the compressor.

- ▶ The existing ambient temperature or intake temperature must be in the range -20 °C to +36 °C.

1.9 Lubricant

We recommend using our fully synthetic high-performance lubricant, Silol.


If you use exclusively Silol or Silol FG (foodgrade) the interval for an oil change **doubles** to a max. **12 months**. The period of the manufacturer's warranty for new compressor units **is extended to 2 years**.

NOTE

For recognition of the guarantee extension, proof of the maintenance interval using Silol or Silol FG is required.

Depending on the operating conditions, brand-name motor oils with API classification SJ/CF as per SAE J183 can also be used.

The respective viscosity class (SAE class) can be taken from the following diagram.



1.10 Screw compressor type plate

The type plate is attached to the side of the screw compressor. It contains the following information:

- Type
- Serial number
- Rotational speed range
- Max. volume flow
- At max. operating pressure
- Max. power consumption

NOTE

The complete identification has certificate value and may not be changed or rendered illegible.

1.11 Compressor unit type plate

The type plate on the compressor unit is attached to the mounting console.

It contains the following information:

- Type
- Year of Manufacture
- Compressor serial no.
- Unit serial no.
- V-belt drive ratio
- Unit drive speed
- Intake volume
- Max. operating pressure

NOTE

The complete identification has certificate value and may not be changed or rendered illegible.

2 Safety

2.1 General

This operating manual contains basic instructions to be followed during operation and maintenance/repair. Therefore, this operating manual must be read by the responsible technical staff/operator prior to commissioning and it must always be available at the place of use for the screw compressor.

2.2 Authorised personnel, training and qualification

Work carried out on the compressor, such as operation and maintenance/repair, must only be carried out by persons with the appropriate authorisation, training and qualifications, who are familiar with the valid safety regulations.

Repairs or modifications must only be performed by authorised personnel who is available at any time at the service sites or at GHH RAND.

2.3 Safety-conscious work

The essential safety-related regulations for installation, operation and maintenance/repair of air compressors are contained in the following publications:

Machinery Directive 2006/42/EC

Standards, in particular:

DIN EN ISO 12100-1/2	Safety of machinery
DIN EN 1012-1	Compressors and vacuum pumps, safety requirements

The regulations of the professional associations, in particular:

BGI 666	Sample operating instructions for operation of container vehicles for granular or dust-like goods (silo vehicles).
---------	--

In this context, the respectively last applicable versions of these regulations shall be authoritative. Special legal provisions and regulations, particularly safety regulations, that may apply in your company or due to local conditions must also be adhered to. In case of competing regulations, the more restrictive provisions shall be applied. You must also observe any national regulations in the respective country of use.

2.4 Safety instructions for the owner/operator

The owner/operator is responsible for ensuring that the screw compressor is in a safe operational condition. Damaged or faulty parts must be immediately replaced. If the screw compressor is used to convey combustible materials, make sure that the temperature remains below the spontaneous ignition temperature for any dust/air mixture which may be created. In accordance with the professional association regulation BGI 666, for the pneumatic transport of materials subject to dust explosion, a temperature limit of max. 120 °C must be adhered to (measurement point before contact with the materials to be conveyed).

2.5 Unauthorised conversions and spare parts

Conversions and modifications to the screw compressor and screw compressor unit are not permitted. Damage to the seal will void any warranty claims. Original replacement parts and accessories that are authorised by the manufacturer represent safety factors. The use of non-original or unauthorised replacement and accessory parts may void the liability for resulting consequences.

2.6 Incorrect operating methods

WARNING

INCORRECT OPERATING METHODS!

The operation of the compressor under incorrect conditions may lead to serious injuries and significant material damage.

- ▶ The compressor must only be operated under permitted conditions.

Unless approval is obtained from GHH RAND, the compressor must only be operated under the conditions stated in *Chapter 1.6 on page 8* to *Chapter 1.8 on page 10*.

2.7 Disposal

Compressor components, as well as operating materials used in conjunction with the screw compressor and compressor unit must be disposed of observing the local regulations.

3 Operation

3.1 Safety during operation

NOTE

Also observe the safety instructions in *Chapter 2 on page 12*.

⚠ DANGER**RISK OF EXPLOSION!**

For the conveyance of combustible, dust-like materials, the temperature of the compressed air at the measurement point directly before contact with the material to be conveyed may not exceed the maximum value of 120 °C.

- ▶ If the maximum temperature is exceeded, switch off the compressor immediately.

⚠ CAUTION**NOISE GENERATION!**

A greater acoustic pressure level can result in damage to hearing.

- ▶ Wear hearing protection.

⚠ CAUTION**HOT MACHINE PARTS!**

During operation, the compressor is very hot. There is a risk of burning on hot machine parts.

- ▶ Wear protective gloves.

NOTICE**OVERHEATING DUE TO EXCESSIVE RUNNING TIME!**

Exceeding the max. running time results in tangible damage due to overheating.

- ▶ Adhere to the max. running time: 3 hours running time and a subsequent 1 hour pause.

NOTICE**OVERHEATING DUE TO EXCESSIVE OPERATING PRESSURE!**

Exceeding the max. operating pressure results in tangible damage due to overheating.

- ▶ Do not operate the compressor at an operating pressure of more than 2.5 bar.
- ▶ In the event of operating at high altitudes, adapt the operating pressure.
- ▶ If exceeded, switch off the compressor.

3.2 Initial commissioning

Initial commissioning of the compressor is usually carried out on the premises of the system manufacturer.

It includes removing the preservation, filling the oil tank and checking the direction of rotation.

3.3 Installation

- ▶ Park the vehicle in as level a position as possible.
- ▶ Observe the permitted inclination.


Permitted inclination

NOTICE

INSUFFICIENT LUBRICATION!

Excessive inclination results in irregular level of lubricant in the housing.

- ▶ Observe the maximum permitted inclination of the screw compressor during operation:
 - To the front and to the rear: 10°
 - To the right and left: 10°



3.4 Switching on

NOTICE

RISK OF BLOWBACK OF MATERIAL!

If the compressor is started if there is counter pressure, there is the risk of damage to the non-return flap due to blowback of material.

- ▶ Only start the compressor when completely depressurised.
- ▶ Never go into operation against a potentially existing counter pressure.


NOTICE

INSUFFICIENT FRESH AIR SUPPLY CS1050 IC!

For vehicles with side cladding installed, the side cladding must be folded down or removed before switching on the compressor unit in order to prevent temperature damage to the compressor.

- ▶ Ensure sufficient fresh air supply.

- ▶ Switch on power take-off.



3.5 Monitoring operation

3.5.1 CS85/external installation

The manufacturer installs a gauge (measurement position in the following pipeline) pneumatic system to monitor the compression pressure. The system manufacturer or external installer must also install displays that monitor the intake negative pressure and the oil pressure of the compressor stage. For the operation and control of the operating displays, only the instructions from the manufacturer are applicable. The permitted operating conditions and limit values can be found in *Chapter 1.6 on page 8* to *Chapter 1.8 on page 10*.

NOTE

With external installations, displays from diverse manufacturers can be installed. Also observe the instructions from the manufacturer.

3.5.2 CS1050 LITE


Oil pressure gauge

The oil pressure is displayed on the oil pressure gauge (1). The oil pressure may not drop below 0.3 bar.

NOTICE**LOW OIL PRESSURE!**

If the oil pressure is insufficient, significant tangible damage can occur.

- ▶ Do not fall below the minimum permitted oil pressure.
- ▶ If, after a short time of operation, no oil pressure is built up, switch off the compressor and check the oil level, as necessary clean the oil intake strainer.



Maintenance indicator variant 1

The negative pressure in the compressor is displayed on the maintenance indicator **(1)**.


The negative pressure must not exceed 65 mbar (red area on the maintenance indicator).

NOTICE

PERMITTED NEGATIVE PRESSURE EXCEEDED!

Excessive negative pressure (> 65 mbar) can result in overheating and damage to the compressor.

- ▶ Clean the intake filter elements of the compressor or, in the event of excessive clogging, replace the filter (*Chapter 4.4.4 on page 27*).



Resetting the maintenance indicator

If the negative pressure has dropped to below the permitted limit (65 mbar, red area on the maintenance indicator), the maintenance indicator must be reset after rectification of the malfunction.

- ▶ Push the button **(2)** on the front of the maintenance indicator **(1)**.

Maintenance indicator variant 2

The negative pressure in the compressor is displayed on the maintenance indicator **(2)**.


The negative pressure must not exceed 65 mbar. The service display **(1)** is then red.

NOTICE

PERMITTED NEGATIVE PRESSURE EXCEEDED!

Excessive negative pressure (> 65 mbar) can result in overheating and damage to the compressor.

- ▶ Clean the intake filter elements of the compressor or, in the event of excessive clogging, replace the filter (*Chapter 4.4.4 on page 27*).




Resetting the maintenance indicator

If the negative pressure has exceeded the permitted limit (service display **(1)** is red), the maintenance indicator must be reset after rectification of the malfunction.

- ▶ Push the button **(3)** on the top of the maintenance indicator **(2)**.

3.5.3 CS1050 IC



1. Cooling fan speed selector switch
2. Operation and fault monitoring
3. Compressed air temperature indicator
4. Negative pressure maintenance indicator
5. Oil pressure display

Once the compressor unit has started and the min. oil pressure has been reached, the control unit switches on automatically.

Oil pressure display

The oil pressure is displayed on the oil pressure gauge. The oil pressure may not drop below 0.3 bar.

NOTICE

LOW OIL PRESSURE!

If the oil pressure is insufficient, significant tangible damage can occur.

- ▶ Do not fall below the minimum permitted oil pressure.
- ▶ If, after a short time of operation, no oil pressure is built up, switch off the compressor and check the oil level, as necessary clean the oil intake strainer.

Negative pressure maintenance indicator

The negative pressure in the compressor is displayed on the maintenance indicator (1).


The negative pressure must not exceed 65 mbar (red area on the maintenance indicator).

NOTICE

PERMITTED NEGATIVE PRESSURE EXCEEDED!

Excessive negative pressure (> 65 mbar) can result in overheating and damage to the compressor.

- ▶ Clean the intake filter elements of the compressor or, in the event of excessive clogging, replace the filter (*Chapter 4.4.4 on page 27*).



Resetting the maintenance indicator

If the negative pressure has dropped to below the permitted limit (65 mbar, red area on the maintenance indicator), the maintenance indicator must be reset after rectification of the malfunction.

- ▶ Push the button **(2)** on the front of the maintenance indicator **(1)**.

Operation and fault monitoring

The operating display lights up green continuously when the compressor is operating.

The operating display does not light up if the oil pressure is too low.

NOTICE

OVERHEATING DUE TO INSUFFICIENT HEAT DISSIPATION!

To prevent temperature damage to the compressor unit if the fan fails for emergency operation, remove the cover.

- ▶ If a sheet of paper held in front of the fan screen is not pushed away from the fan when it is running, remove the cover.

Compressed air temperature indicator

The compressed air temperature is measured after the cooling air outlet and indicated on the compressed air temperature indicator.

Cooling fan speed selector switch

The fan speed can be set in two positions with the selector switch:

- Left pos.: "HOT" reduced cooling power
- Right pos.: "COOL" maximum cooling power

3.6 External oil cooler for compressor (optional)

To ensure that the compressor has an optimum service life even under extreme conditions, an external oil cooler can be connected as an option.

3.6.1 Function control of external oil cooler fan

A sheet of paper held in front of the radiator of a running fan must be sucked towards it.

NOTICE

DAMAGE TO THE COMPRESSOR!

The compressor can be damaged if the fan is defective.

- ▶ Check that the fan works.
 - The paper is sucked in by the fan.

3.7 Switching off

NOTICE

RISK OF BLOWBACK OF MATERIAL!

If the compressor is switched off if there is counter pressure, there is the risk of damage to the non-return flap due to blowback of material.

- ▶ Do not turn compressor off if there is counter pressure!
- ▶ If there is counter pressure, take appropriate measures to reduce pressure before switching off the compressor.

NOTE

The non-return flap installed in the compressor unit prevents the compressor from running backwards rapidly and for a long time (as a result of residual pressure in the compressed air lines of the pneumatic system) after being shut down.

- ▶ Switch off power take-off.

NOTE

Before switching off, do not manually reduce the compressor speed using the speed control.

NOTICE

COMPRESSED AIR LINE NOT DISCONNECTED!

The compressed air line ruptures if it is not disconnected from the compressor unit before starting the journey. Internal components of the compressor unit can also be damaged.

- ▶ Disconnect the compressed air line from the compressor unit before starting journey.

NOTE

After switching off the IC compressor unit, the fan of the air cooler continues to run until the air temperature in the IC unit is below 50 °C.

3.8 Preservation

If the compressor is shut down for an extended period of time, the compressor must be protected from corrosion damage using a preservative. Please consult the manufacturer for a recommendation of a suitable preservative.

4 Maintenance/repair

4.1 Safety

NOTE

Also observe the safety instructions in *Chapter 2 on page 12*.

WARNING

COMPRESSED AIR IN THE SYSTEM!

There is a risk of injury due to pressurized components and lines.

- ▶ All checks and maintenance tasks must only be performed with the compressor switched off and depressurised.
- ▶ Remove the ignition key from the towing vehicle.

CAUTION

HOT MACHINE PARTS!

During operation, the compressor is very hot. There is a risk of burning on hot machine parts.

- ▶ Wear protective gloves.

NOTICE

CLEANING USING A HIGH-PRESSURE JET!

When cleaning a silo vehicle using a high-pressure jet, there is the possibility that water will ingress into the interior of the compressor and the air filter.

- ▶ A distance of 0.5 m must be maintained.
- ▶ If necessary, empty or clean the air filter.
- ▶ In order to prevent corrosion, after cleaning, the compressor must be briefly operated (approx. 10 minutes).

4.2 Observe the tightening torques

The tightening torques are specified in the following chapters.

WARNING

INCORRECT TIGHTENING TORQUE!

An incorrect tightening torque can endanger the secure attachment of the compressor, or result in damage to components due to excessive tightening torque.

- ▶ The specified tightening torques must be observed.

4.3 Maintenance Intervals

All of the maintenance and repair tasks given on this page are described in detail in the following *Chapter 4.4 on page 23*.

After the first 2 operating hours	Section
Readjust the tension of the V-belts and quick-release bushings of the V-belt pulleys.	4.4.1
Re-tighten the fastening screws on the discharge silencer.	4.4.2
Perform a visual inspection of the lines to/from the oil cooler and compressor to make sure they do not leak (optional).	3.6
Weekly	
Check the oil level in the compressor and correct as required.	4.4.3
Clean the intake filter or replace if the degree of contamination is excessive and reset the negative pressure maintenance indicator as required.	4.4.4
Check the tension of the V-belts and adjust as necessary.	4.4.1
Quarter-annually	
Carry out a function check of the safety valve.	4.4.5
Carry out a function check of the non-return flap.	4.4.6
Check the air cooler blades for dirt and clean as needed (IC unit).	4.4.7
Every six months or, if using Silol, once per year	
Carry out an oil change.	4.4.8
Clean the oil intake strainer.	4.4.8

4.4 Maintenance work

4.4.1 Readjusting the tension of the V-belts and quick-release bushings of the V-belt pulleys

NOTE

For the maintenance of the belt drive of a compressor unit based on the CS85 compressor stage (third-party manufacturer), only the instructions from the manufacturer are applicable.

The following applies to the CS1050 unit:

NOTICE


ELONGATED V-BELT!

During the initial 2 operating hours, due to settling, the V-belts elongate and quick-release bushings of the V-belt pulleys lose the correct pretensioning.

- ▶ After the initial 2 operating hours, the V-belts and quick-release bushings of the V-belt pulleys must be retensioned.


CS1050 LITE:

- ▶ Loosen the screw connections (2 - 3) and take off the V-belt cover (1).



CS1050 IC:

- ▶ Loosen the screw connections (2 - 5) and take off the V-belt cover (1).



Adjusting the tension of the quick-release bushings of the V-belt pulleys

- ▶ Retighten the V-belt pulley screws (1 and 2).


Quick-release bushing tightening torques

Belt pulley nominal diameter	Quick-release bushings	Tightening torque
180 mm	3020	90 Nm
200 mm		
224 mm		
250 mm		
280 mm	3525	112 Nm
315 mm		

Checking and setting the tension of the V-belt

- ▶ Use an appropriate measuring device (e.g. Opti-belt) to check the V-belt tension.
- ▶ The belt can then be tightened by mechanical measurement or by measurement of the sound waves (belt frequency), according to the selected measuring device.
- ▶ During the check, follow the operating instructions provided by the manufacturer of the measuring device and adhere to the setpoint values for belt tension listed in the device's operating instructions.
- ▶ In order to correct the belt tension, loosen the counter nut (3) and retighten the V-belt (5) by turning the adjusting screw (4).
- ▶ Tighten the lock nut (3).

Tightening torque (M16 A2-70): 155 Nm



NOTE

When tensioning the belt, make sure you follow the operating instructions provided by the manufacturer of the measuring device.

Make sure that the instructions for the SPB/XPB V-belt type are used.

NOTICE

INCORRECT V-BELT TENSION!

Excessive V-belt tension can lead to bearing damage and broken shafts. If the V-belt tension is too low, the V-belts can slip during operation and thus wear out prematurely.

- ▶ The V-belt tension must be adjusted according to the manufacturer of the measuring device.

Reinstall the V-belt cover.


Tightening torque (M8 A2-70): 18 Nm

4.4.2 Retightening the fastening screws on the discharge silencer

CS1050 LITE

Remove the upper unit covering in order to access the discharge silencer screws.

- ▶ Unscrew the screws (1) from the upper cover (2).
- ▶ Lift the cover off.




- ▶ Tighten the fastening screws (2) on the discharge silencer (1), tightening one screw then tightening the screw opposite.

Tightening torque (M12 A2-70): 65 Nm

- ▶ Reinstall the cover.


Tightening torque (M8 A2-70): 18 Nm



CS1050 IC

Remove the upper unit covering in order to access the discharge silencer screws.

- ▶ Unscrew the screws (1) from the upper cover (2).
- ▶ Lift the cover off.




- ▶ Tighten the fastening screws (2) on the discharge silencer (1), tightening one screw then tightening the screw opposite.

Tightening torque (M12 A2-70): 65 Nm

- ▶ Reinstall the cover.

Tightening torque (M6 A2-70): 7 Nm




4.4.3 Checking the oil level

- ▶ Unscrew the oil dipstick (1) (unit).
- ▶ Unscrew the oil dipstick (2) (CS85).
- ▶ Clean the oil dipstick (1/2) with a lint-free cloth and screw it back in completely.
- ▶ Unscrew and remove the oil dipstick (1/2) again and check the oil level.

NOTE

The oil level must be between the marks "min." and "max." on the dipstick. The difference between the markings is approximately 1 litre.

- ▶ Correct the oil level as needed.



4.4.4 Cleaning and replacing the intake filter element

For the maintenance or replacement of the intake filter of a compressor unit based on the CS85 compressor stage (third-party manufacturer), only the instructions from the manufacturer are applicable.

NOTE

Intake filters from diverse manufacturers can be installed. Also observe the instructions from the manufacturer.

CS1050 LITE:


- ▶ Unfasten the wire bracket catches (2) from the air filter housing (1) and then remove the cover (3).
- ▶ Clean filter elements by lightly tapping or replace if necessary.

NOTICE

INCORRECT FILTER CLEANING!

Do not clean filter elements with compressed air, benzine or other liquids.

- ▶ Only clean or replace the filter element according to the instructions.
- ▶ Press the dust release valve at the bottom of the air filter housing so that the collected dust/dirt falls out.
- ▶ Assembly occurs in reverse order.



CS1050 IC:


- ▶ Loosen the screws (1) on the compressor unit and then remove the cover (2).
- ▶ Remove filter elements (3).
- ▶ Clean filter elements (3) by lightly tapping or replace if necessary.

NOTICE

INCORRECT FILTER CLEANING!

Do not clean filter elements with compressed air, benzine or other liquids.

- ▶ Only clean or replace the filter element according to the instructions.
 - ▶ Assembly occurs in reverse order.
- Tightening torque (M12 A2-70): 65 Nm**




4.4.5 Check the safety valve

The safety valve is usually installed on the discharge silencer.

NOTE

The discharge silencers **(1)** supplied by GHH RAND have an integrated safety valve **(2)**.



- ▶ In order to check the knurled nut **(1)**, release the safety valve **(2)**. The valve seat **(3)** must open when released.
- ▶ Tighten the knurled nut **(1)** on the safety valve **(2)**.
- ▶ Replace safety valve as necessary.


NOTE

When installing a new safety valve, heed the manufacturer's instructions.

⚠ WARNING**DANGER OF BURSTING!**

No safety valve with a size other than the one provided and/or with a higher response pressure must be used.

- ▶ Only use the safety valves provided.



4.4.6 Check the non-return flap

For the maintenance or replacement of the non-return flap of a compressor unit based on the CS85 compressor stage (third-party manufacturer), only the instructions from the manufacturer are applicable.


NOTE

Non-return flaps from diverse manufacturers can be installed. Also observe the instructions from the manufacturer.

The discharge silencers supplied by GHH RAND have an integrated non-return flap.

- ▶ Remove the cover.
- ▶ Lift off the belt guard.
- ▶ IC unit only:
open the cooling system and hose band clamp at the discharge head.
- ▶ Remove the pressure pipe (1) by releasing the screw connections (2-3).
- ▶ Remove the non-return flap (4) and seals.
- ▶ Check the non-return flap (4) is working smoothly, replace the non-return flap (4) if necessary.
- ▶ Installation is carried out in the reverse sequence. Pay attention to the correct position of the non-return flap (4).

Tightening torque (M12 A2-70): 37 Nm



NOTICE

DAMAGE DUE TO A DEFECTIVE NON-RETURN FLAP!

Improper assembly can cause damage.

- ▶ When reassembling, always use new seals.
- ▶ Never operate the compressor unit without a non-return flap.
- ▶ Pay attention to the proper installation position of the non-return flap. The side marked with "TOP" must point upwards.


4.4.7 Testing and cleaning the air cooler

NOTE

Only with the IC unit.

- ▶ Remove the cover.
- ▶ Check the air cooler (1) for dirt, if necessary blow out the air cooler with compressed air.
- ▶ Install the cover.

Tightening torque (M6 A2-70): 7 Nm



4.4.8 Oil change and cleaning the oil intake strainer

CAUTION

ENVIRONMENTAL POLLUTION THROUGH OIL!

Very small quantities of oil are sufficient to make significant amounts of potable water unusable.

- ▶ During the oil change, make sure that no oil is released into the environment.
- ▶ Dispose of the used oil in accordance with local regulations.

NOTICE

DAMAGE DUE TO INCORRECT OILS!

Incorrect oils can destroy the compressor.

- ▶ Only use specified oil (*Chapter 1.9 on page 10*).

NOTICE

INCORRECT OIL LEVEL!

If the oil level is insufficient, significant tangible damage can occur. If the oil level is excessive, foaming and, thus, oil leakage can occur.


- ▶ Observe the fill quantity.

- ▶ Unscrew and remove the oil drain plug (**1 and 3**) from the compressor housing.
- ▶ Collect the oil in a suitable container.

NOTE

To remove the oil intake strainer (**5**), loosen the V-belt tensioner if necessary (*Chapter 4.4.1 on page 23*).

- ▶ Unscrew and clean the oil intake strainer (**5**).
- ▶ Screw in the oil intake strainer (**5**).
Tightening torque (M20x1.5): 40 Nm
- ▶ Install the oil drain plug (**3**) with a new seal ring (**4**).
Tightening torque (M30x2): 130 Nm
- ▶ Install the oil drain plug (**1**) with a new seal ring (**2**).
Tightening torque (M20x1.5): 70 Nm
- ▶ Top up oil, filling quantity approx. 8.5 litres.



NOTE

Seal ring (**4**): DIN 7603 - A30x36 - soft iron.

Seal ring (**2**): DIN 7603 - A21x26 - soft iron.

5 Faults, cause and instructions for troubleshooting

If in doubt, switch off the compressor!

Fault	Possible cause	Remedy	Section
Air quantity not sufficient	Drive speed too low	Increase drive speed to the maximum permitted speed	1.6 - 1.8
	Suction filter soiled/clogged	Clean or replace filter cartridges or elements as necessary	4.4.4
Ultimate air pressure too high	Nominal diameter of the compressed air line too small	Install new lines with a larger nominal diameter	-
	Non-return flap faulty	Check the non-return flap	4.4.6
	Safety valve does not open	Check the safety valve	4.4.5
	Drive speed too high	Reduce the drive speed to the maximum permitted speed	1.6 - 1.8
Ultimate air temperature too high	Intake filter soiled	Clean or replace filter cartridges or elements as necessary	4.4.4
	Ultimate air pressure too high	Check the safety valve	1.6 - 1.8
	Ambient temperature too high	Observe permitted intake temperature	1.6 - 1.8
	Blades of the air cooler dirty (IC unit)	Check air cooler	4.4.7
	Fan not running (IC unit)	Check control and cable connection	-
		Replace the fuse of the feed line	-
Negative pressure greater than 65 mbar	Check the fan selector switch position	3.5.3	
	Intake filter soiled	Clean or replace filter cartridges or elements as necessary	4.4.4
	Drive speed too high	Reduce the drive speed to the maximum permitted speed	1.6 - 1.8
Oil pressure less than 0.3 bar	Clean the oil intake strainer	4.4.8	
	Oil level too low	Check oil level and top up as necessary	4.4.3 & 4.4.8
	Wrong type of oil	Drain oil completely and top up with specified oil	4.4.8
	Drive speed too low	Increase drive speed to the maximum permitted speed	1.6 - 1.8
	Bent or damaged oil lines on units with an external oil cooler (optional)	Check oil lines and oil cooler	3.6

Fault	Possible cause	Remedy	Section
Oil foams	Wrong type of oil	Drain oil completely and top up with specified oil	4.4.8
	Water in the oil		
	Oil quality different		
	Oil level too high	Check oil level and drain off oil as necessary	4.4.3 & 4.4.8
Oil leaks	Oil level too high	Check oil level and drain off oil as necessary	4.4.3 & 4.4.8
	Screw connections leaking	Check screw connections	–
Oil pressure fluctuates	Oil level too low	Check oil level and top up as necessary	4.4.3 & 4.4.8
	Excessive inclination of the compressor	Observe the max. permitted inclination	3.3

Printed in Germany

Reserves the right to amend technical details compared to the information and illustrations of the operating manual. A replication, copying or translation, even in parts, is not permitted without written consent.

As a contribution to environmental protection:

This paper has been produced from 100% chlorine free bleached pulp.

GHH RAND®

Service & Support

www.ingersollrand.com/ghhrandtransport



Subject to revision without notice

Printed in Fed. Rep. of Germany

12/2022 EN